



## **Industrial peristaltic pump LD-LIVP-A11**

**Labodam Equipment Ltd.**  
**[info@labodam.com](mailto:info@labodam.com) | [www.labodam.com](http://www.labodam.com)**

# Industrial peristaltic pump LD-LIVP-A11

## Overview

Industrial peristaltic pump LIVP-A11 is a dual channel precise dispensing peristaltic pump to transfer large amount of fluid in industry. Equipped with varied flow range and speed accuracy it allows reversible operation to pump in both directions. Includes time dispensing, volume dispensing and copy dispensing mode to meets all kinds of complex dispensing requirements. Provides high levels of volumetric accuracy without contaminating the fluid during the operation. Interchangeable pump heads help in delivering smooth and low pulse flows

## Features:

- Touch screen display to set dispense volume, stop time, copy number etc
- Autosave™s running parameters on power or system failure
- Reversible operation allowing pumping in both directions
- Easy liquid auto dispensation by time or volume
- Acid, alkali, sodium corrosion resistant
- Dust and moisture proof circuit board
- Adjustable rotating speed
- Robust and protected with ABS plastic housing
- Low noise operation

## Specifications:

<b>Weight</b>	15 kg
<b>Display</b>	Touch screen display
<b>IP grade</b>	IP 31
<b>Flow Range</b>	0.01 - 13 L/min
<b>Speed Range</b>	0.1 ~ 600 rpm
<b>Power supply</b>	AC 220 V $\pm$ 10 % , 50 Hz / 60 Hz
<b>Flow Accuracy</b>	0.5 %.
<b>No of channel</b>	2
<b>Speed Resolution</b>	1 rpm
<b>Power Consumption</b>	< 300 W
<b>Relative Humidity</b>	< 80 %
<b>Ambient Temperature</b>	0 ~ 40 °C
<b>Dimensions ( L x W x H )</b>	350 x 235 x 315 mm