

labodam



DEHUMIDIFIER LD-LDHU-A10

Dehumidifier LD-LDHU-A10

Dehumidifier LD-LDHU-A10 is electrical refrigeration humidifier unit with powerful moisture removal capacity of 24 L/ day. It works by drawing moist air over a refrigerated evaporator with a fan. Features digital display humidity monitor which shows current air humidity. It consumes low power energy efficient the auto modes are automatically adjusting the humidity levels.

Features:

- ▶ Effectively removes moisture, dust from the air
- ▶ Humidity levels are automatically adjusted
- ▶ Designed with system Auto shut-off / auto restart
- ▶ Quiet fan has two speed settings
- ▶ Laundry drying function
- ▶ 24-hour timer to set the time of operation
- ▶ Electronic control Panel
- ▶ Device content antibacterial filters
- ▶ Performs Continuous drainage or 5 L water tank
- ▶ Auto-Defrost at low temperature

Applications:

Dehumidifier applied across diversified industries like pharmaceutical, food, lithium battery manufacturing, defense, power, chemicals, electronics, leather and many more. They are successfully installed across research and development (R&D), manufacturing, processing, drying, testing, storage and packaging areas in almost all industries.

Specifications:

Model No.	LD-LDHU-A10
Dehumidifying capacity (at 30°C and 80% RH)	24 L / 24 h (01 day)
Water Tank	5.0 L
Refrigerant	R290
Noise	≤ 43 dB (A)
Input power	280 W

Dehumidifier LD-LDHU-A10

Input current	1.25 A
Loading Quantity	324 / 666/ 888
Supply Voltage	AC 220 V to 240 / 50 Hz
Dimension (D×W×H)	310 × 210 × 565 mm
Net Weight	13.5 kg